

Nightstick Product Battery Replacement Information

Product Part Number	How to Open Battery Compartment	Tool Required	Battery Type & Quantity	Replacing AA, AAA or AAAAA Alkaline w/ Rechargeable	Replacing CR-123 w/ Rechargeable	Battery Carrier Required	Nightstick Rechargeable Upgrade Option	Nightstick Rechargeable Replacement Battery	Intrinsically Safe Certification Alkaline Battery Requirements**
FDL-300R	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
FDL-300R-K01	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
MT-100	Unscrew Tail Cap	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-100BL	Unscrew Tail Cap	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-100CTD	Unscrew Tail Cap	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-100R	Unscrew Tail Cap	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-110	Unscrew Tail Cap	None	1 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-120	Unscrew Tail Cap	None	2 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-130	Unscrew Tail Cap	None	2 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-140B	Unscrew Tail Cap	None	2 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-200	Unscrew Tail Cap	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-210	Unscrew Tail Cap	None	1 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-220	Unscrew Tail Cap	None	2 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-230	Unscrew Tail Cap	None	1 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-90	Unscrew Tail Cap	None	1 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MTU-106	Unscrew Tail Cap	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MTU-136	Unscrew Tail Cap	None	2 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1102A	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1136	Slide Battery Cover toward base of light	None	4 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1162	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1164	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1166	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1168	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only* ₁	N/A	No	No	N/A	N/A

Product Part Number	How to Open Battery Compartment	Tool Required	Battery Type & Quantity	Replacing AA, AAA or AAAA Alkaline w/ Rechargeable	Replacing CR-123 w/ Rechargeable	Battery Carrier Required	Nightstick Rechargeable Upgrade Option	Nightstick Rechargeable Replacement Battery	Intrinsically Safe Certification Alkaline Battery Requirements**
NSP-1170	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1172	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1174	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1174-K01	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1176	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1178	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1180	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1206B	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1206R	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1224B	Slide Battery Cover toward base of light	None	4 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1224CTD	Slide Battery Cover toward base of light	None	4 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1224R	Slide Battery Cover toward base of light	None	4 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1236	Slide Battery Cover toward base of light	None	4 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1260	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1310CTD	Unscrew Cap at base of light	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1310RM	Unscrew Cap at base of light	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1312RM	Unscrew Cap at base of light	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1400B	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1400R	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1400T	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1402B	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1404B	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1632	Unscrew Cap at base of light	None	3 - AAA	NiCad or NiMH Only*	N/A	AAA Carrier	No	N/A	N/A
NSP-1634	Unscrew Cap at base of light	None	3 - AAA	NiCad or NiMH Only*	N/A	AAA Carrier	No	N/A	N/A

Product Part Number	How to Open Battery Compartment	Tool Required	Battery Type & Quantity	Replacing AA, AAA or AAAA Alkaline w/ Rechargeable	Replacing CR-123 w/ Rechargeable	Battery Carrier Required	Nightstick Rechargeable Upgrade Option	Nightstick Rechargeable Replacement Battery	Intrinsically Safe Certification Alkaline Battery Requirements**
NSP-1636	Unscrew Cap at base of light	None	3 - AAA	NiCad or NiMH Only*	N/A	AAA Carrier	No	N/A	N/A
NSP-2422B	Unscrew Bezel and slide Reflector/LED Module out	None	3 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-2422R	Unscrew Bezel and slide Reflector/LED Module out	None	3 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-410	Unscrew Tail Cap	None	1 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-420	Unscrew Tail Cap	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-430	Unscrew Tail Cap	None	2 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4602B	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver Screwdriver	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4603B	Loosen fitting on back of head & rotate door downward	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4604B	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver Screwdriver	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4605B	Loosen fitting on back of head & rotate door downward	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4606B	Loosen fitting on back of head & rotate door downward	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4608B	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4608BC	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4610B	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4612B	Loosen fitting on rear battery compartment & rotate door downward	None	3 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4614B	Loosen fitting on back of head & rotate door downward	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4616B	Loosen fitting on rear battery compartment & rotate door downward	Phillips Screwdriver	3 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4650B	Loosen fitting on back of light & rotate door downward	Slotted Screwdriver	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
NSP-9842XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	9842-CARRIER	9844-BATT Only	N/A	N/A
NSR-9844XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	9842-CARRIER	No	9844-BATT Only	N/A
NSR-9854XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	9842-CARRIER	No	9844-BATT Only	N/A
TAC-300B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-300B-K01	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-300T	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A

Product Part Number	How to Open Battery Compartment	Tool Required	Battery Type & Quantity	Replacing AA, AAA or AAAA Alkaline w/ Rechargeable	Replacing CR-123 w/ Rechargeable	Battery Carrier Required	Nightstick Rechargeable Upgrade Option	Nightstick Rechargeable Replacement Battery	Intrinsically Safe Certification Alkaline Battery Requirements**
TAC-300Y	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-302B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-302B-K01	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-310XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-350B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-360XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-400B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-400T	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-400Y	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-410XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	560-BATT Only	N/A
TAC-450B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-460XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	560-BATT Only	N/A
TAC-460XL-K01	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	560-BATT Only	N/A	N/A
TAC-500B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-500T	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-500Y	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-510XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	560-BATT Only	N/A
TAC-540XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	560-BATT Only	N/A	N/A
TAC-550B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	560-BATT Only	N/A
TAC-560XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	560-BATT Only	N/A
XPP-5410G	Unscrew Tail Cap	Phillips Screwdriver	2 - AAA	Invalidates IS Certification	N/A	No	No	N/A	Energizer E92, Energizer EN92 Duracell MX2400, Duracell PC2400 or Duracell EN92
XPP-5412G	Unscrew Tail Cap	Phillips Screwdriver	3 - AAAA	Invalidates IS Certification	N/A	No	No	N/A	Duracell MX2500 or Energizer E96
XPP-5420B	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5420G	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91

Product Part Number	How to Open Battery Compartment	Tool Required	Battery Type & Quantity	Replacing AA, AAA or AAAA Alkaline w/ Rechargeable	Replacing CR-123 w/ Rechargeable	Battery Carrier Required	Nightstick Rechargeable Upgrade Option	Nightstick Rechargeable Replacement Battery	Intrinsically Safe Certification Alkaline Battery Requirements**
XPP-5420GX	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5422B	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5422G	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5422GX	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5422GM	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5422GMX	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5450G	Loosen fitting on back of head & rotate door downward	Phillips Screwdriver	3 - AAA	Invalidates IS Certification	N/A	No	No	N/A	Energizer E92 or Energizer EN92
XPP-5452G	Loosen fitting on back of head & rotate door downward	Phillips Screwdriver	3 - AAA	Invalidates IS Certification	N/A	No	No	N/A	Energizer E92 or Energizer EN92
XPP-5454G	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver	3 - AAA	Invalidates IS Certification	N/A	No	No	N/A	Energizer E92 or Energizer EN92
XPP-5454GC	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver	3 - AAA	Invalidates IS Certification	N/A	No	No	N/A	Energizer E92 or Energizer EN92
XPP-5456G	Loosen fitting on rear battery compartment & rotate door downward	Allen Wrench	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5458G	Loosen fitting on rear battery compartment & rotate door downward	Allen Wrench	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5570G	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	5572-BATT Only	N/A	Energizer EN91 or Energizer L91
XPP-5570GA	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	5572-BATT Only	N/A	Energizer EN91 or Energizer L91
XPP-5570R	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	5572-BATT Only	N/A	Energizer EN91 or Energizer L91
XPP-5570RA	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	5572-BATT Only	N/A	Energizer EN91 or Energizer L91
XPR-5572G	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	No	5572-BATT Only	Energizer EN91 or Energizer L91
XPR-5572GA	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	No	5572-BATT Only	Energizer EN91 or Energizer L91
XPR-5572R	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	No	5572-BATT Only	Energizer EN91 or Energizer L91
XPR-5572RA	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	No	5572-BATT Only	Energizer EN91 or Energizer L91
XPR-5572RM	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	No	5572-BATT Only	Energizer EN91 or Energizer L91

* Not offered by Bayco Products. These would be commercially available rechargeable NiCad or NiMH Battery(ies). Do NOT use Lithium-ion Rechargeable Battery(ies)

** Using a different battery other than what is listed will invalidate Intrinsically Safe Certification Rating